

Maintenance Instructions

To maintain a good mechanical function and a fine finish of your LEIAB Windows we recommend that you ensure that the following instructions be adhered to.

1

All moveable parts of the spanjolette and keeps should be oiled at least 1-2 times annually. This includes in and around the closing mechanism. We recommend a silicon spray. Do not use mineral based oils. The closing keeps should also be oiled.

2

To clean the glazing we recommend a high quality window cleaner. Care must be exercised to ensure that the cleaning agent is not too harsh. In the event of blinds being fitted then utmost care must be taken to protect these.

3

The aluminium components should be washed with a mild detergent and dried with a soft cloth. Do not use any solvents as this can damage the aluminium painted surface.

4

The weather gaskets are of silicone and do not require more maintenance than a gentle wiping once a year.

5

To separate the 2 + 1 windows use a small screwdriver to separate the sashes. The coupling fitting should be lightly oiled annually.

6

To clean the blinds, let them fall to the full length, then use a slightly damp cloth, wipe the individual slats allowing them to be totally dry before drawing them together.

Figure 1



Figure 2



Figure 3

